Support and Registration   English | Español

Compatibility

Support Home

Contact Sony Support

Memory Stick® Media Compatibility Information for Sony Digital Cameras

Important Information:

- This "Compatibility Chart" only provides compatibility testing results for the Memory Stick media applications listed in each product's instruction manual with Memory Stick media types listed below.
- This chart does not guarantee support for all Memory Stick media types' performance nor compatibility among Memory Stick media compliant products.
- Memory Stick media transmission speed varies by, and depends on, host hardware devices' features and circumstances of use.

Remarks:

*1 = Data over 128MB cannot be recorded in a single session.
*2 = Memory Stick media with 128MB or 128MBX2 capacity are not compatible with this product type.
*3 = For Memory Stick Duo media ONLY. Standard Memory Stick media cannot be used.
*4 = Transmission speed is restricted by the design of host hardware devices, equal to that of the Memory Stick PRO media.

Legend:

X = No compatibility
O = Only data that does not require copyright protection (MagicGate™ copyright protection technology) can be recorded/played back.
C = Data that requires copyright protection (MagicGate™ copyright protection technology) can be recorded/played back.

Media Type	Memory Stick®	Memory Stick PRO™	Memory Stick PRO™	High Speed Memory Stick PRO™	
Standard Size	32MB/64MB/128MB/ 128MBX2 ***1**	256MB/512MB/1GB	256MB/512MB/1GB/2GB	256MB/512MB/1GB/2GB	4GB
Duo Size	32MB/64MB/128MB	256MB/512MB	256MB/512MB/1GB/2GB	256MB/512MB/1GB	
Models					
Cyber-shot® Cameras					
DSC-F55K	O	X	X	X	X
DSC-F88	O	O	O	O*4	O*4
DSC-F505	O	X	X	X	X
DSC-F505V	O	X	X	X	X
DSC-F707	O	X	X	X	X
DSC-F717	O	O	O	O*4	X
DSC-F828	O	O	O	O*4	O*4
DSC-H1	O	O	O	O	O
DSC-L1	O*3	O*3	O*3	O*3*4	X
DSC-M1	O*3	O*3	O*3	O*3*4	X
DSC-P1	O	X	X	X	X
DSC-P2	O	X	X	X	X
DSC-P3	O	X	X	X	X
DSC-P5	O	X	X	X	X
DSC-P7	O	X	X	X	X
DSC-P8	O	O	O	O*4	X
DSC-P9	O	X	X	X	X
DSC-P12	O	O	O	O*4	X
DSC-P10	O	O	O	O*4	X
DSC-P20	O	X	X	X	X
DSC-P30	O	X	X	X	X

DSC-P31	O	X	X	X	X
DSC-P32	O	O	O	O*4	X
DSC-P41	O	O	O	O*4	O*4
DSC-P50	O	X	X	X	X
DSC-P51	O	X	X	X	X
DSC-P52	O	O	O	O*4	X
DSC-P71	O	X	X	X	X
DSC-P72	O	O	O	O*4	X
DSC-P73	O	O	O	O*4	O*4
DSC-P92	O	O	O	O*4	X
DSC-P93	O	O	O	O*4	O*4
DSC-P100	O	O	O	O*4	O*4
DSC-P120	O	O	O	O*4	O*4
DSC-P150	O	O	O	O*4	O*4
DSC-P200	O	O	O	O*4	O*4
DSC-S30	O	X	X	X	X
DSC-S40	O	O	O	O	O
DSC-S50	O	X	X	X	X
DSC-S60	O	O	O	O	O
DSC-S70	O	X	X	X	X
DSC-S75	O	X	X	X	X
DSC-S85	O	X	X	X	X
DSC-S90	O	O	O	O	O
DSC-T1	O*3	O*3	O*3	O*3*4	X
DSC-T3	O*3	O*3	O*3	O*3*4	X
DSC-T7	O*3	O*3	O*3	O*3	X
DSC-T33	O*3	O*3	O*3	O*3*4	X
DSC-V1	O	O	O	O*4	X
DSC-V3	O	O	O	O*4	O*4
DSC-W1	O	O	O	O*4	O*4
DSC-W5	O	O	O	O	O
DSC-W7	O	O	O	O	O
DSC-W15	O	O	O	O	O
Cyber-shot® U Cameras					
DSC-U10	O	X	X	X	X
DSC-U20	O	X	X	X	X
DSC-U30	O	O	O	O*4	X
DSC-U40	O*3	O*3	O*3	O*3*4	X
DSC-U50	O*3	O*3	O*3	O*3*4	X
DSC-U60	O	O	O	O*4	X
Mavica® Cameras					
MVC-FD92	O	X	X	X	X
MVC-FD100	O	X	X	X	X
MVC-FD200	O	X	X	X	X